



## Recessed Niche Installation Guidelines

### Standard Shampoo and Soap Niches:

- Tile-EZ Standard Shampoo and Soap Niches are designed to be installed between two wall studs and incorporate a ½” overlap permitting the niche face to be flush with conventional cement board.



- Install a cross support member below and above where niche is to be placed between studs.
- Using 100% Silicone Sealant on back and sides of niche, place niche in place and adhere to adjacent wall studs and the back or outside wall.
- Install wall board to studs around the niche opening.
- Insert a bead of silicone between niche and the wall board. Tape joints with cement board tape.
- Apply tile to niche using a water-based thin-set.

Technical Support / Questions  
Tel: 856-673-8747  
Fax: 856-235-5410  
Email: ANGEPAN@Tile-EZ.com

[www.Tile-EZ.com](http://www.Tile-EZ.com)